



# Tricycle

# Tricycle TUKTUK TAXI Motorcycle Clutch Assembly G4070500 For TVS KING

### **Basic Information**

• Place of Origin: Guangdong, China

Brand Name: WAY-C
Model Number: TVS KING
Minimum Order Quantity: 100 pieces

• Price: \$10.00/pieces 12-99 pieces

Packaging Details: Box+CARTONDelivery Time: 30-45days

• Payment Terms: L/C, D/A, D/P, T/T, Western Union,

MoneyGram

• Supply Ability: 20000 Piece/Pieces per Month



## **Product Specification**

Model: TVS KING

• Product Name: Clutch Assembly

MOQ: 90PCSMaterial: Iron

• Quality: High Qaulity

Shipping: Sea Transport.Air Transport Air Express
Port: NANSHA/HUANGPU, GUANGZHOU

• Parts NO: G4070500

• Highlight: Tricycle Motorcycle Clutch Assembly,

TAXI Motorcycle Clutch Assembly, G4070500

Our Product Introduction

#### **Product Description**

### G4070500 Tricycle TUKTUK MOTO TAXI Clutch Assembly for TVS KING

#### **Products Description**

Product name	Clutch Assembly
Model	TVS KING
Materials	Metal
Parts NO	G4070500
Packing	Вох
Shipping	Sea/Air
Place of origin	Guangzhou,China



The clutch assembly in a tricycle serves the same purpose as in a motorcycle or other vehicles with manual transmissions. It is responsible for engaging and disengaging the power transmission between the engine and the drivetrain. The clutch allows the rider to smoothly start the tricycle from a standstill, change gears, and come to a stop without stalling the engine.

Here are the main components typically found in a tricycle clutch assembly:

Clutch Disc: The clutch disc is a friction plate that is located between the engine's flywheel and the clutch pressure plate. It has a hub in the center that connects to the transmission input shaft. The clutch disc consists of friction material on both sides, which engages and disengages with the flywheel and pressure plate to transmit power.

Pressure Plate: The pressure plate is a spring-loaded component that applies pressure to the clutch disc, clamping it against the flywheel. When the clutch pedal is released, the pressure plate holds the clutch disc tightly, allowing power to be transmitted from the engine to the transmission.

Flywheel: The flywheel is a heavy rotating disk connected to the engine's crankshaft. It provides inertia and smooths out engine vibrations. The clutch disc engages with the flywheel, transferring power from the engine to the transmission.

Clutch Release Bearing: The clutch release bearing, also known as the throw-out bearing, is a component that engages and disengages the pressure plate from the clutch disc. It is typically located inside the clutch housing and moves along a release fork when the clutch pedal is pressed.

Clutch Housing: The clutch housing is the enclosure that contains the clutch assembly. It is usually bolted to the engine and houses the clutch disc, pressure plate, and release bearing.



#### **PACKING & SHIPPING**

#### GUANGZHOU WAY-C TRADING CO.,LTD.











5-7 working days WWW.TNT.COM

5-7 working days WWW.EMS.COM.CN

5-7 working days WWW.DHL.COM

5-7 working days WWW.UPS.COM

5-7 working days WWW.FEDEX.COM



Why Choose Us

**OUR ADVANTAGES** 

GUANGZHOU WAY-C TRADING CO.,LTD.

# Why choose us?

- 1. High quality: Using high quality material and establishing a strict quality control system, assigning specific persons in charge of each part of production, from raw material purchase to assembly.
- 2. Professional models for motorcyle parts and three wheeler parts, we have one group to focus on the new models parts, so welcome to OEM and ODM orders
- ♦ 3. Fast dispatch: Most of the products are in stock. Quality below 100pcs can be delivered within 15 days.
- 4.Small order accepted: Low MOQ accepted.50pcs are available.



# GOUNG PARTS GUANG ZHOU WAY-C I HADING CO.,LID

NO.356 Baiyun Motorcycle Parts Market, Zengcha Road, Baiyun District, Guangzhou